

Installation Details

Concrete Floor Attachment

- No. 8 Steel Center Standards with Formed Foot

Chairs mounted to concrete floors are to be anchored with two 1/4" x 3-1/4" Hilti Wedge Bolt anchors as illustrated below. Anchors are set in holes drilled at precise measured locations in the concrete riser. Anchors are 1/4"-18 thread with cone-shaped heads, and have an expansion sleeve (wedges) that slides down the expansion cone when the 1/4"-18 nut is tightened against the standard. This mechanical expansion allows for immediate load application.

